

# Welcome to eSlate!



*Click anywhere on this slide to continue:*

## eSlate Slide4

### The Buttons



Turn the **SELECT** wheel to highlight your choices.



Press **ENTER** to vote for a selected choice.



Use the **CAST BALLOT** button to cast your ballot.



Use **PREV** to go to the previous page.

Use **NEXT** to go to the next page.



Press **HELP** to get help.

*Click anywhere on this slide to continue:*

## eSlate Slide5

### Select Your Language

1. Turn the **SELECT** wheel until the language you want is highlighted in red.



7. Press **ENTER** to make your selection.

*Click anywhere on this slide to continue:*

## Enter Your Access Code

<b>ACCESS CODE</b>			
Cedeno, Carlos			
<b>4192</b>			
Time: 11:43:2007			
Time: 11:43:31			
Place: Main Election			

4			
1	2	3	
4	5	6	
7	8	9	
Back	0	Clear	

1. Turn the **SELECT** wheel to highlight the first number of your Access Code.
2. Press **ENTER** to choose that number.
3. Repeat for all numbers of your Access Code.
4. When the last digit in your code has been entered, you will see the first page of your ballot.

*Click anywhere on this slide to continue:*

## Make Ballot Choices

Council Member

 Abraham Lincoln

☐

Alexander Hamilton

Council Member

☒

Abraham Lincoln

☐

Alexander Hamilton

1. Turn the **SELECT** wheel until your choice is highlighted in blue.
2. Press **ENTER**. The box to the left of your choice will turn red to show your vote.
3. The blue highlight bar will move to the next contest title.
4. Continue through the ballot until you have voted all the contests you wish to vote.
5. You may use the **PREV** or **NEXT** buttons at any time to move through the ballot.

*Click anywhere on this slide to continue:*

## How to Do a Write-in Candidate

Enter Write-In Candidate

Candidate Name

A	B	C	D	E
F	G	H	I	J
K	L	M	N	O
P	Q	R	S	T
U	V	W	X	Y
Z	Cancel	OK		

Cancel OK

Press -HELP for help or info

*Click anywhere on this slide to continue:*



## Review Your Ballot



### Ballot Summary Page

To change a vote, highlight the contest to change and press ENTER.

Contest	Selected
<b>PRESIDENT/VICE PRESIDENT</b>	U Gary Brown/Art
UNITED STATES SENATOR	No selections
GOVERNOR	Harlan Tideman
ATTORNEY GENERAL	No selections
MAYOR	No selections
COUNTY JUDGE	No selections



Press PREV for previous page.  
To complete your voting and cast your ballot,  
press CASEY BALLOT.

- ✓ After you have voted all the pages of the ballot, a Ballot Summary page appears, allowing you to review your selections.
- ✓ To change your vote, turn the **SELECT** wheel until the contest you want to change is highlighted, then press **ENTER**. You will return to that contest.
- ✓ You may use the **PREV** and **NEXT** buttons to review your ballot.

*Click anywhere on this slide to continue:*

## Cast Your Ballot

When you have completely finished voting  
all races and reviewing your Ballot Summary  
page, press the **CAST BALLOT** button.




*Click anywhere on this slide to continue:*



## Cast Your Ballot

Your vote has been recorded when you  
see the waving American Flag.



*Click anywhere on this slide to continue:*